Water heater/boiler.

Boiler is located under the bed of starboard aft cabin and boil the water by engine cooling system when the main engine is on and by 220v when the boiler switch on into outlet and on

220v control panel as well.





Hot water regulation valve.