## 14. Refrigeration

The system on this boat is an upgraded 12v vertical 140L refrigerator. This system is designed to run 24hrs a day if you wish. There is a front loading unit with a small freezer compartment. Be sure that you follow below mention two main rules:

- Firstly, keep your batteries charged. If the level goes below 12.2v the system will malfunction. Refer to section 7 for charging instructions.
  The hermetic of the refrigerator allows cold food to stay cold until morning. In any case, spoiled milk is much more chepper of killed batteries for eur800.
- Secondly, do not chip at the ice or use any other sharp items in the fridge. If something is frozen to the fridge do not force it away. Warm water on it if you need to melt it away.

There is a thermostat in the fridge. It is a white dial with numbers on it going from 1-7. Putting 7 at the apex of the dial is the coldest setting. Keep it on this setting until it is too cold. Then you can turn the system down or off if you wish.

Front loading fridge

